



Thank you for choosing Prodigy Disc for your Professional Disc Golf Targets!

Our targets are used for Pro Tour and Disc Golf Major Championships. Prodigy Targets are preferred by top Professionals and world class courses.

THE SPECS

THE TARGET

Dimensions:

56 inches tall
22 inches around the top

THE HOLE

10 inches wide x 36 inches deep

This is required for the install of the ground sleeve and concrete.

THE GOODS

MATERIALS YOU'LL NEED

- Concrete
- Fill Dirt
- Gravel
- Duct Tape

RECOMMENDED TOOLS

- Level
- Shovel
- Tape Measure
- Tamper
- Auger or Post Hole Digger

THE HOW-TO

INSTALLING A TARGET

- 1 Dig a Hole.**

10 inches wide x 36 inches deep. (48 inches in colder climates.)
Fill the bottom 12 inches (24 inches in colder climates) with $\frac{3}{4}$ clear gravel and tamp.
- 2 Place the ground sleeve in the ground to check for depth.**

Aim for the top of the sleeve to be 2" above ground level. This allows for easy access to the lock. Remove the ground sleeve after inspecting the depth.
- 3 Fill hole with concrete mix.**

Keep in mind to leave enough space under the lock loop to allow for easy access of the lock.
- 4 Seal the bottom of the sleeve with duct tape and place it into the wet concrete.**

Ensure that the sleeve reaches the bottom of the hole and concrete does not get inside the sleeve.
- 5 Using a level, check that the ground sleeve is level in the concrete.**

To do this, insert pole into sleeve and put level on the pole.
- 6 Allow time for the concrete to dry with the sleeve.**
- 7 Install basket, apply lock, and add backfill dirt into the hole.**

